

Water Demand Study

Corey Hutchison

Diagram 1

191

- = 5ft of height
- M = meter
- BF = backflow
- PA = pressure assembly
- BP = booster pump

